



Inline Fluid Filter Kit

406898A

ENG



Important Safety Instructions

Read all warnings and instructions in your pump or package manual. Save all instructions.


Kit 24F271, Stainless Steel Kit 24F272, Aluminum

Ref.	Description	Qty.
101	COUPLER	1
102	SEAL	1
103	HOUSING, filter (includes swivel)	1
104*	FILTER, 60 mesh	1
105	FITTING, swivel, 1/4 -18 npsm x 1/4-18 npt	1
106	FITTING, 1/4-18 npsm x 1/4-18 npt	1
107	SEALANT, pipe; 2 ml	1

* The following filter replacement kits are available:
 287032 Filter, 60 mesh (qty 1)
 287033 Filter, 100 mesh (qty 1)
 287034 Filter, 60 mesh (qty 1) and 100 mesh (qty 1)


Assembly

1. Remove fluid outlet fitting (A) from pump.
2. Apply pipe sealant (107) to threads and install inline fluid filter assembly.
3. Remove the coupler (101) from the housing (103) to replace or clean filter. Torque to 120-130 in-lb (14-15 N•m).



⚠ Apply pipe sealant (107) to threads.

⚠ Torque to 120-130 in-lb (14-15 N•m).



Graco Inc. P.O. Box 1441 Minneapolis, MN 55440-1441
 Original instructions. This manual contains English. MM 406898
 Copyright 2010, Graco Inc. is registered to ISO 9001

